

# NORMAN®

## SHUTTERS. BLINDS. SHADES.

### Maintenance and Cleaning

#### Shutters and Blinds

Use a clean, dry feather duster, cloth or vacuum with brush attachment to gently remove dust and debris. To ensure thorough cleaning, wipe the louvers or slats in the open and closed positions. Do not immerse the product in water or use abrasive chemical solvents. This may cause discoloration and the wood to warp. Ultrasonic cleaning is not recommended. For best results on Woodlore® Shutters use a cotton cloth dampened with water. Polyester cloths tend to create static, which can attract dust.

#### Honeycomb Shades

Use a clean, dry feather duster, vacuum with a brush attachment or compressed air/hair dryer at a cool setting to remove dust and debris. For spot cleaning, use a soft cloth or sponge moistened with lukewarm water. Add mild detergent if needed. Blot gently to avoid creasing the shade. Dry in the lowered position. For significant residue build up, professional ultrasonic cleaning may be used.

#### Roller Shades

Roller shades can be cleaned by handheld vacuum, spot cleaning or dusting. For spot cleaning use a soft cloth or sponge moistened with lukewarm water. Add mild detergent if needed. Blot gently to avoid creasing or damaging the fabric. Rubbing can damage the fabric. Do not iron roller shade fabrics.